


AUTOMATIC WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS


Illus. No.	Part No.	DESCRIPTION
1 2	357213	Nut, Push-In (2) Top
2	3949476	For Designer White Model
	3949477	For Designer Almond Model
3	62750	Spacer, Cabinet To Top (4)
4	3349654	Cabinet–Sound Damper
5	63424	Cabinet For Designer White Model
	63425	For Designer Almond Model
6	62780	Clip, Top & Cabinet & Rear Panel (2)
8	3356311	Screw & Washer, Lid Switch (2)
11 13	3949237 3351355	Switch, Lid Screw, Lid Hinge Mounting (4)
15 16	54584 54583	Hinge, Lid (L.H.) Hinge, Lid (R.H.)
17 18	19119 21258	Bumper, Lid Hinge Bearing, Lid
19	3352718	Hinge (2) Lid For Designer White Model
	3352719	For Designer Almond Model
20 22 28	358684 93770 384435	
31 32	90016 3362952	Clip, Harness Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

CONTROLS AND REAR PANEL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	16123	Washer, Water	16		Cap, End (L.H.)	44		Knob, Timer
		Inlet Hose (4)		3358528	For Designer		3948580	For Designer
		(1-1/16 x 5/8)			White Model			White Model
3		Hose, Water		3358529	For Designer		3948582	For Designer
	00.40000	Inlet (2)	۱ ۵	222222	Almond Model	45		Almond Model
		Hose (Inlet)	18	3360392	Valve, Water	45	2040507	Dial, Timer
4		Hose (Inlet)	19	00864	Mixing Screw,		3948587	For Designer White Model
4		Screw, 8A x 3/8	19	30004	10-24 x 3/8 (2)		20/18588	For Designer
5 6		Hinge, Console (2) Panel, Rear	20	694419	Mini–Buzzer		3940300	Almond Model
7		Pad, Rear Panel	21		Clamp, Hose	48		Knob, Control
8		Hose, Drain	22		Hose, Vacuum	40	3950759	For Designer
O	0001000	(4 ft.)			Break		0000.00	White Model
	661577		23	371503	Clamp, Hose		3950760	For Designer
	00.0	(9 ft.)	24		Break, Vacuum			Almond Model
		(Not Included)	25		Support, Rear	49	388326	Screw, 8-18 (2)
	3357090	Extension,			Panel			(Panel to Top)
		Drain Hose	26	3361809	Connector, Drain	50	62863	Screw, 10-16 x 3/8
		(21 Inches)			Hose	51		Cap , End (R.H.)
		(Not Included)	27		Clamp, Hose_		3358513	For Designer
9	3951703	Timer, Control	28	3359816	Hose, Pump To			White Model
		(60 Hz.)		2040407	Drain		3358514	For Designer
		(Motor Not A	29		Switch, Cycle		0057044	Almond Model
4.0	0057007	Service Part)	30 31		Clamp, Hose	55	3357011	
10	3357027	Nozzle-Drain	32		Clamp, Hose Hose, Pump To Tub	50	2266042	10–16 x 1/2
40	2266047	Hose	32	3930340	(Includes #30)	58	3300913	Clamp, Drain Hose
12 13		Switch, Water Level Bracket, Control	35	661613	Switch, Cycle	59	3348434	Shield, Suds
14		Cord, Power	36		Screw, Timer	60		Harness, Wiring
14	3949240	(Power Cord Only	"	0-100000	Mounting	00	3331703	(Includes Power
		Without Harness)			(10–32 x 1) (2)			Cord)
15	3949468	Strain Relief,	39		Panel, Console			(For Detail See
.0	00 10 100	Power Cord		3948284	For Designer			Page 9 & 10) Also
					White Model			See Clips.
				3948285	For Designer			- 1 -
					Almond Model			
			40	661614	Switch, Water			
					Temperature			

AGITATOR, BASKET AND TUB PARTS




AGITATOR, BASKET AND TUB PARTS

IIIus. No.	Part No.	DESCRIPTION
1	63580	Dispenser
2	358237	Screw & Washer (5-16-24 x 1)
3 4	3363003 3347288	Clothes Mover Agitator
5	63851	Tub Ring & Gasket
6	3359585	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3363663	
10	3366877	Dog, Agitator Clutch
11	3363661	Bearing, Driven Cam
12	21366	
13	3350649	Basket & Balance
. •		Ring
14	3361948	
16	388893	Tub
		(Includes Item 25)
17	389140	
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure
		Switch
20	3946501	Agitator
		(Complete Asy.)
22	3350389	Spacer, Thrust
23	3347290	Cap, Barrier
24	3348855	Seal, Inner Cap
25	3948705	Hose, Bleach
26	3949550	Washer

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Models: LSQ9244EQ0, LSQ9244EZ0 (Designer White) (Designer Almond)


		(Designe	r White) (Designer Ali	mond)		
@	Illus.	Part		Illus.	Part	
	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
	140.	140.	DESCRIPTION	140.	140.	DESCRIPTION
	1	388952	Brake & Drive	11	62611	Plate, Motor
	•	000002	Tube (Complete)			Mount To
			(Refer to Page 12			Gearcase
			For Further	12	62691	Grommet, Motor (4)
			Breakdown)	13		Coupling, Motor
	2	63292	Washer, Spin			& Isolation
	_	00_0_	Tube Thrust	15	3355454	
2	3	62697	Ring, Spin			Anti-Rattle
	-		Tube Support	16	3357334	Screw
3	4	63283	Ring, Retainer	17	3349637	Retainer, Motor (2)
•	5	3951311	Clutch (Complete)	18		Shield, Tub
4	6		Band & Lining,			To Motor
4	•	000.000	Clutch (Includes	19	661600	Motor, Main
			Illus. 7 & 8)			Drive
5	7	62646	Cap, Clutch	20	62850	Switch, Main
7	•		Spring (2)			Drive Motor
	8	3951303	Spring, Clutch	21	62700	Retainer, Pump (2)
	9	3360630	Gearcase	22		Pump (Complete)
Own	Ū		(Complete)	23	3387485	Screw, 10-16 x 5/8
			(Refer To Page 13	24		Shield, Motor
6 8			For Further	25		Screw,
15			Breakdown			10-16 x 3/8
	10	3357334	Screw, Gearcase	26	357021	Capacitor
L — — — — — —			To Base (3)	27		Clamp, Capacitor
Ĭ						
Щ						
				7		
			,,	/		
		_)		
			/ 0	- 1		
				/-		
9	The state of the s	1				10
	9}	1				1 8
10	اللهُ اللهُ	1	` \	8	23	3 19
		` \		₽ -		,
		6	一16			
	_ >	<u>^</u>	17	-		
	@ ′ 、	(C) >	17	₽		
	/	` (@)	` \	/		
, , , , , , , , , , , , , , , , , , ,	/			1	20 <	
11/			\ \	·	7	`\
12			\ \ \ / /		C \	
10		~ ·			100	
13		~ ~	/ / / \		// N/0)	
24		\sim	< \	(/o2%)		
24				Y (T/(@Z		The state of the s
		\sim		(B)	>(`\\	21
			25	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	`, `\	_22
	26		•	~ }	7 7	
	26		×		(
		27		₹	ر ۶	
	_			٦		
			47/	i		8
			1/	一		₹
			23	9		



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSQ9244EQ0, LSQ9244EZ0 (Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSQ9244EQ0, LSQ9244EZ0 (Designer White) (Designer Almond)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4	388498 3347812 3352501	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)
5 6		Clip, Harness Clip, Harness	14	3347243	Block, Disconnect (Use Term. 352088)	23	3349494	Connector, Etc
7		Retainer, (Suds Models)	15 16		Protector Connector	24	60687	Connector, Relay (Use Term.308569 Or 338664.)
8	352090	Timer, Block Disconnect (White)			(2–Way) (Use Term.94614)	25 26		E.T.C. Control Connector (T.P.A.)
9	352089	Timer, Block Disconnect (Black)	17	387566	Plug, Terminal (4–Way) (Power Cord) (Use M3 Screws)			(3-Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19	3352944 3390423	Clip, Harness	27	3360056	Connector (T.P.A) (3–Circuit) (Pressure Switch) (Use Term.3948619 OR 3948620.)
11	353424	Or 94614.) Plug, Terminal (3-Way)	20	3347730	Receptacle (6–Way) (Use Term. 94613)	28	3354925	Block, Connector (Cold Valve) (Use Term.693217)
40	00505	(Power Cord) (Use Term.94613)	21	388818	Plug, Terminal (12–Way)	29	3354926	Block, Connector (Hot Valve)
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)			(Use Term. 94613 Or 94614.)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6–Circuit) (Temp. Switch) (Use Term.3948619 OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2F

WATER SYSTEM PARTS

For Models: LSQ9244EQ0, LSQ9244EZ0 (Designer White) (Designer Almond)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6 7	65349 367031	Clamp, Hose Drain Protector (Not Included)

BRAKE AND DRIVE TUBE PARTS

For Models: LSQ9244EQ0, LSQ9244EZ0
_____(Designer White) (Designer Almond)




IIIUS.	Part	
No.	No.	DESCRIPTION
1	388952	Brake And Drive
•	00000_	Tube (Complete)
2 3 4 5	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket
Ū	0.02.	Drive (Includes
		Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
8 9	62703	"T" Bearing,
		Spin Tube
10	62648	Cap, Brake
		Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake
		Spring
13	63023	Cam, Brake
		Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake
		Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

GEARCASE PARTS



MISCELLANEOUS PARTS

For Models: LSQ9244EQ0, LSQ9244EZ0 (Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	3976252	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose
4	3359452	(1–1/16 x 5/8) (4) Nut, Lock (3/8–16)
5 7		Foot, Front (2) Clamp, Hose

LITERATURE AND OPTIONAL PARTS

Illus. Part
No. No. DESCRIPTION

LITERATURE PARTS

LIT3950952 Sheet, Installation Instructions LIT3366864 Guide, Use and Care LIT3949009 Energy Guide LIT3951704 Label, Wiring Diagram

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT4313896 Manual (Washer)

Illus.	Part		lllus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017 White 72107 Almond 72110 Golden Harvest

PAINT, PRESSURIZED SPRAY

(13 oz.)

350938 Primer, Gray 350930 White 350956 Almond 261890 Golden Harvest

PAINT, BULK (1 qt.)

799344 White (Uncut) 978883 Almond (Uncut) 261891 Golden Harvest (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

SHIPPING KIT

3348675 Shipping Kit

ACCESSORY PARTS

89121 Stand-Pipe Kit 367031 Drain Protector 285320 Siphon Break Kit